


MOUNTING INSTRUCTIONS



- On the basis of the stem thread, choose the correct extension and nut; mount the extension **(1)** on the valve spindle through the nut **(2)**;
- screw the nut **(3)** on the extension **(1)**;
- mount the hub **(4)** on the valve bonnet through the screws **(5)** which have to engage on the valve neck in correspondance to the groove **(6)**;
- the valve can now be coupled with MVE actuator following the relating mounting instructions.